

EQ-F6 Quick Start Manual

Contents

EQ-F6 Quick Start Manual.....	1
Keypad Layout.....	3
Using Handset / Hands-free Speaker / Headphone.....	4
Screen User Interface.....	4
Hold.....	6
Speakerphone.....	6
Mute.....	6
Blind Transfer.....	6
Announced Transfer / Attended Transfer.....	6
3-Way Conference.....	7
Call Pickup.....	7

Fig 1. Keypad Layout



- ① Soft-menu buttons
- ② Hold
- ③ Transfer
- ④ Conference
- ⑤ Navigation keys+OK
- ⑥ Contacts
- ⑦ Call Log
- ⑧ Standard Telephone Keys
- ⑨ MWI
- ⑩ Headset
- ⑪ Redial
- ⑫ Hands Free
- ⑬ Page-Switch(PS) Key
- ⑭ DSSKEY Keys
- ⑮ Volume Low
- ⑯ Mute
- ⑰ Volume High

Keypad Layout

The above picture shows the keypad layout of the device. Each key provides its own specific function. User should refer to the illustration in this section about the usage of each key and the description in this document about each function.

Some keys support long-pressing function. User can press and hold the key for 1.5 seconds to trigger the long-pressed function.

- Soft-menu Buttons – These four buttons provide different functions corresponding to the soft-menu displayed on the screen.
- Standard Telephone Keys – The 12 standard telephone keys provide the same function as standard telephones, but further to the standard function, some keys also provide special function by long-pressing the key,
- Key # - Long-pressed to lock the phone. (Default PIN is 1234)
- Navigation Keys – User can press up/down navigator keys to change line focus in talking screen or move cursor in a screen with list items; in some configuration or text editor screen, user can press left/right navigator keys to switch option or move cursor to the left / right.
- Hold – Press "hold" button during the call, the user can hold the call, press again to cancel the call to maintain, return to normal call state.
- Transfer – Press the "Transfer" button, the user can transfer the current call to other numbers.
- Conference – Press the "Conference" button, the user can initiate a three-party conference.
- Redial – By pressing 'Redial' button, user can redial the last dialed number.
- Hands-free Speaker – By pressing this button once, user can turn on the audio channel of hands-free speaker
- Pn / Page-Jump – By pressing this button with a number which ranges from 1 - 5, user can switch specific DSS LCD page.
- Volume Low – In standby, ringing, ring configuration screen, user can press this button to lower the ringtone volume; in talking and audio volume adjustment screen, user can press this button to lower the audio volume.
- Microphone Mute – User can mute the microphone with this button during talking mode.
- Volume High – In standby, ringing, ring configuration screen, user can press this button to increase the ringtone volume; in talking and audio volume adjustment screen, user can press this button to increase the audio volume.

Using Handset / Hands-free Speaker / Headphone

Using Handset

To talk over handset, user should lift the handset off the device and dial the number, or dial the number first, then lift the handset and the number will be dialed. User can switch audio channel to handset by lifting the handset when audio channel is opened in speaker or headphone.

Using Hands-free Speaker

To talk over hands-free speaker, user should press the hands-free button then dial the number, or dial the number first then press the hands-free button. User can switch audio channel to the speaker from handset by pressing the hands-free button when audio channel is opened in handset.

Using Headphone

To use headphone, by default, user should headset button which is defined by DSS key to turn on the headphone. Same as handset and hands-free speaker, user can dial the number before or after headphone turned on.

Using Line Keys(Defined by DSS Key)

User can use line key to make or answer a call on specific line. If handset has been lifted, the audio channel will be opened in handset, otherwise, the audio channel will be opened in hands-free speaker or headphone.

Screen User Interface



① Main Screen

① Soft-Menu Buttons


The screen user interface is mostly presented in the above layout except some prompt messages. The upper area is the main screen to display the device's status and information or data for viewing or editing. The lower area is the software menu (soft-menu) buttons which will change against user's action or device's status.

The above picture shows the default standby screen which is also the root of the soft-menu. The default standby screen shows the greeting words and effective feature indications like voice message, missed call, auto-answering, do-not-disturb, call forward, lock state, and the network

connectivity. User can get back to the default standby screen mostly by lifting and putting by the handset.

In some screens, there are more items or long text to be displayed which could not fit into the screen.

They will be arranged in a list or multiple lines with a scroll bar. If user sees a scroll bar, user can use up/down navigator buttons to scroll the list or items in a faster speed.



Hold

1. Press HOLD key during conversation. The call is on hold now.
2. Press HOLD again to unhold

Speakerphone

1. Press SPEAKERPHONE button during conversation.

The call is on speakerphone now.

2. Press SPEAKERPHONE button again to use the handset.

Mute


1. Press MUTE button to mute.
2. Press it again to unmute.

Blind Transfer

1. Press TRANSFER key during conversation.

The call is on hold now.

2. Enter the number you are transferring to.
3. Press SEND or TRANSFER key to complete a blind transfer.



Announced Transfer / Attended Transfer

1. Press TRANSFER key during conversation.

The call is on hold now.

2. Enter the number, extension or press BLF key you are transferring to.
3. Press DIAL soft key.
4. Start a second conversation, press SEND or TRANSFER key to complete an announced transfer.



3-Way Conference

1. Press CONFERENCE key during conversation.

The call is on hold now.

2. Enter in the number, extension or BLF key you are conferencing with and press DIAL soft key or press SEND.

3. When the person answers, press CONFERENCE key.



Call Pickup

When someone's phone ringing and you'd like to pickup that call on your phone:

press STAR '8' or flashing BLF key

